

## IFP6530, IFP7530, IFP8630 Touch FW Update Instruction


### Note:

- FW update tool only for Windows 7 or above.
- Please do not remove any cables during FW update.
- Please download specify FW file for your display.

1. Connect your PC and display by Touch USB and HDMI cables.


Switch source to HDMI and make sure touch feature is working normally.

*\*\* it is ok if run on an Intel OPS slot-in PC.*





2. Unzip FW files, double click on “UpgradeTool.exe”


*\*\* Here take IFP7530 as sample*



3. Select FW file > Pick up correct FW file> Open > Upgrade




## IFP6530, IFP7530, IFP8630 Touch FW Update Instruction



Update process will be finish in few minutes. Do not remove any cables when it is in process.

4. Please wait for 30 seconds for touch feature resume when you see the screen.



5. For the best touch performance...

- Please reboot display after do FW update.
- Keep display aspect ratio setting on PTP for 4K signal source.

