

WPG-370 Firmware Update Instructions

1. Download the firmware file, unzip the file onto the root directory of a USB stick. The firmware filename is "install.img".
2. Plug the USB stick to the USB port on the front of the WPG-370.
3. Use HDMI interface and connect to a display.
4. Plug in the power adapter.
5. Press and hold the "Mode Change" button on the side of the WPG-370 and the "Power" button at the same time.
6. Release both buttons when the firmware update screen shows up.
7. Wait until the firmware update is successful. The WPG-370 will automatically reboot.
8. After reboot, remove the USB stick.