







# Thin Client Monitor Quick Start Guide



1



2



3







# Thin Client Monitor Quick Start Guide





## ViewSonic Corporation (US/Canada/Latin America)


 : <http://www.viewsonic.com/support/product-registration>  
 : 381 Brea Canyon Road, Walnut, CA 91789-0708, USA





### United States

 1-800-688-6688  
1-424-233-2530  
 [service.us@viewsonic.com](mailto:service.us@viewsonic.com)



### Canada

 1-866-463-4775  
1-424-233-2533  
 [service.ca@viewsonic.com](mailto:service.ca@viewsonic.com)



### Latin America (Mexico)

 55)6547-6454 55)6547-64846  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)



### Latin America (Columbia)

 <http://www.viewsonic.com/la/soporte/servicio-tecnico>  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)



### Latin America (Chile)

 <http://www.viewsonic.com/la/soporte/servicio-tecnico>  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)



### Latin America (Peru)

 <http://www.viewsonic.com/la/soporte/servicio-tecnico>  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)

### Latin America (Argentina)

 <http://www.viewsonic.com/la/soporte/servicio-tecnico>  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)

### Puerto Rico & Virgin Islands

 1-800-688-6688  
<http://www.viewsonic.com/la/soporte/servicio-tecnico>  
 [soporte@viewsonic.com](mailto:soporte@viewsonic.com)  
[service.us@viewsonic.com](mailto:service.us@viewsonic.com)



## ViewSonic Europe Ltd.

 : <http://www.viewsoniceurope.com>  
 : Level 10, Tower 42, 25 Old Broad St., London EC2N 1HQ, United Kingdom  
 : +44 (0) 207 382 8251



### Europe

 [www.viewsoniceurope.com/uk/](http://www.viewsoniceurope.com/uk/)

### Deutschland

 [www.viewsoniceurope.com/de/](http://www.viewsoniceurope.com/de/)

### España

 [www.viewsoniceurope.com/es/](http://www.viewsoniceurope.com/es/)

### Suomi

 [www.viewsoniceurope.com/ff/](http://www.viewsoniceurope.com/ff/)

### France

 [www.viewsoniceurope.com/fr/](http://www.viewsoniceurope.com/fr/)

### Россия

 [www.viewsoniceurope.com/ru/](http://www.viewsoniceurope.com/ru/)



## 优派科技（中国）有限公司 ViewSonic China Limited

 : [http://www.viewsonic.com.cn/?fservice\\_register](http://www.viewsonic.com.cn/?fservice_register)  
 : 上海邮政082-008信箱



### 中国

 4008 988 188  
 [service.cn@cn.viewsonic.com](mailto:service.cn@cn.viewsonic.com)



## ViewSonic International Corporation



 : <http://www.viewsonic.com.tw>  
 : 9F, No.192, Lien Chen Rd., Zhonghe Dist., New Taipei City 235, Taiwan, R.O.C.  
 : 886 (2) 2249-1751



### 台灣

 0800 061 198  
 [service@tw.viewsonic.com](mailto:service@tw.viewsonic.com)

### Singapore/Malaysia/Thailand

 65 6461 6044  
 [service@sg.viewsonic.com](mailto:service@sg.viewsonic.com)


### India

 1800 266 0101  
 [service@in.viewsonic.com](mailto:service@in.viewsonic.com)

### Australia

 1800 880 818  
 [service@au.viewsonic.com](mailto:service@au.viewsonic.com)


### 香港

 852 3102 2900  
 [service@hk.viewsonic.com](mailto:service@hk.viewsonic.com)



### 한국

 080 333 2131  
 [service@kr.viewsonic.com](mailto:service@kr.viewsonic.com)




### South Africa

 [ap.viewsonic.com/za/](http://ap.viewsonic.com/za/)

### New Zealand

 0800 008 822  
 [service@au.viewsonic.com](mailto:service@au.viewsonic.com)

## 美商優派國際股份有限公司

 : <http://www.viewsonic.com.tw>  
 : 台灣新北市中和區連城路192號9樓  
 : 886 (2) 2249-1751