

## Touch Screen Modes - Additional Information

Mode	Note
<p>Normal Mode (This is the default setting)</p>	<ul style="list-style-type: none"> <li>• Finger touch support.</li> <li>• Multi-touch support.</li> <li>• Wet hand touch support (touch with wet and undried hands).</li> <li>• Supports passive pen click and basic writing. Do not write too quickly. (5mm)</li> <li>• Supports palm rejection (25 mm x 25 mm).</li> </ul>
<p>Pen Touch Mode</p>	<ul style="list-style-type: none"> <li>• Pencil touch support (2 mm).</li> <li>• Stylus touch support (3.5 mm).</li> <li>• Supports various active pens and click touch:<sup>™</sup> MPP 2.0<sup>™</sup> Apple<sup>™</sup> Wacom AES<sup>™</sup> Google USI</li> <li>• Supports pen click and basic writing. Do not write too quickly.</li> <li>• Supports palm rejection (25 mm x 25 mm).</li> <li>• When a pen and a finger are both on the TD2465, only the pen signal will be detected. Handwriting and pen writing cannot operate at the same time.</li> <li>• Does not support touch input with wet hands.</li> <li>• Does not support active pen protocol or pressure levels.</li> </ul>
<p>Glove Touch Mode</p>	<ul style="list-style-type: none"> <li>• Supports various types of glove material. NOTE: Supported glove material can be found on the TD2465 product page.</li> <li>• Supports one finger touch and click, or two fingers gesture; up to 5-point touch.</li> <li>• Do not move your finger(s) too quickly.</li> <li>• Gloves should be fitted and close to your fingers.</li> <li>• Palm rejection is not supported.</li> </ul>
<p>Water Resistant Touch Mode</p>	<ul style="list-style-type: none"> <li>• Touch supported even with some moisture on the screen.</li> <li>• A moving water droplet will not cause an incorrect input.</li> <li>• Supports one finger touch and click; up to 5-point touch.</li> <li>• Do not move your finger(s) too quickly.</li> <li>• Palm rejection is not supported.</li> </ul>