

ViewSonic[®]
See the difference[™]




IFP50-3

How to: Identify Firmware version


Subject: Identify Firmware version.
IFP5550-3, IFP6550-3, IFP7550-3, IFP8650-3
(including - 3A/B).

Identify your Firmware version.


Go to: Setting> System> About device:




Mode name= IFPxx50-3, please download IFPxx50-3_**BE**_xxxxxxx

EX:  IFP6550-3(BE) Main Firmware

Mode name= IFPxx50-3_CT2, please download IFPxx50-3_**CT**_xxxxxx

EX:  IFP6550-3(CT) Main Firmware

Model Name= IFP8650-3 please get the FW package IFP8650-3_**LD**_xxxxxxx

EX:  IFP8650-3(LD) Main Firmware