



---

## **Projector Software Update User Guide**

# How do I Use the Projector Software Update?


**IMPORTANT: ONLY USE THE CORRECT FIRMWARE TO UPDATE THE PROJECTOR.**

**FAILURE TO DO SO MAY CAUSE DAMAGE TO THE PROJECTOR.**

## 1. Download the Projector Software

Visit ViewSonic's website to download the projector software:


<https://www.viewsonic.com/>



## 2. Hardware Connection


Connect one end of a Mini USB cable to the projector's service port, and connect the other end of USB-A cable to your computer.

Continuously press the projector's Power key and Menu Key until the LED began to flash while connected to a power outlet.




### 3. Run the Software Update Program

After you have successfully downloaded the software, double click on the file.



### 4. Confirm to Upgrade Projector

Please read the Warning message and press the “**Upgrade Now**” button to confirm the update.




**Warning:** If you are failed during the download process, please refer following steps to reactivate the firmware update process.

- Connect the USB cable.
- Continuously press the projector's Power key and Menu Key while connected to a power outlet.
- The LED will begin to flash.
- Downloading will restart.

## 5. The Program Will Start Automatically


The software update program will start automatically, please wait for few minutes until it is completed.



## 6. The Software Update is Completed


Click "Exit" once the update has finished

**IMPORTANT! Do not turn off the projector or computer while updating.**



## 7. Firmware Version Check

Turn on the projector and go to the “**INFORMATION**” page to check the firmware version.





**ViewSonic®**