

ViewSonic®



**Projector Software Update
User Guide**

How do I Use the Projector Software Update?


IMPORTANT:

1. ONLY USE THE CORRECT FIRMWARE TO UPDATE THE PROJECTOR.
FAILURE TO DO SO MAY CAUSE DAMAGE TO THE PROJECTOR.
2. ONLY AVAILABLE FOR Windows 10.

1. Download the Projector Software

Visit ViewSonic's website to download the projector software:


<https://www.viewsonic.com/>



2. Hardware Connection


Connect one end of a USB cable to the projector's service port, and connect the other end of USB-A cable to your computer.

Continuously press the projector's **Power** key and **Menu** Key until the LED began to flash while connected to a power outlet.




3. Run the Software Update Program

After you have successfully downloaded the software, double click on the file.



4. Confirm to Upgrade Projector

Please read the Warning message and press the “**Upgrade Now**” button to confirm the update.




Warning: If the download process fails, please refer to the following steps to reactivate the firmware update process.

- A. Connect the USB cable.
- B. Continuously press the projector’s Power key and Menu Key while connected to a power outlet.
- C. The LED will begin to flash, and downloading will restart.

5. The Program Will Start Automatically


The software update program will start automatically, please wait for a few minutes until it is completed.



6. The Software Update is Completed


Click "Exit" once the update has finished

IMPORTANT! Do not turn off the projector or computer while updating.



7. Firmware Version Check

Turn on the projector and go to the “**INFORMATION**” page to check the firmware version.





ViewSonic®