ViewSonic®

Mac easy gesture control for IFP60

1. Single Finger
   a. One finger single click -> Left mouse click
   b. One finger double click -> Left mouse double click

2. Two Fingers
   a. Two fingers pitch or spread -> zoom in/out photo or screen
   b. Two fingers rotate for photo
   c. One finger put on screen and click by another finger -> Right mouse click

3. Three Fingers
   Swipe left/right -> previous/next web page

4. Four Fingers
   a. Swipe left/right -> swipe between full screen apps
   b. Swipe up -> Mission control
   c. Swipe down -> App expose

5. Five Fingers
   Five Finger Spread/Pinch to show desk/apps